# i-SCAN 3e Features Overview

i-SCAN 3e Hardware Features


8" IPS LCD Touch Screen

CR2032 PCB Battery
For Perpetual Calendar

⚠ WARNING
TO AVOID ELECTRICAL SHOCK REMOVE
TEST LEADS BEFORE OPENING CASE.
OPERATION VOLTAGE RANGE:
11~28 V DC
TEMPERATURE RANGE:
0~50°C (41~122°F)
AUTOLAND SCIENTECH CO., LTD.
MADE IN TAIWAN

Speaker

Reset Button

RJ45 Ethernet Cable (F)

USB Port (Master)

USB Port (Slave)

12 ~24V DC Input

15-PIN Diagnostic Adaptor

i-SCAN 3e Basic Functions

Vehicle Diagnostic
Package includes diagnostic, setting,
programming and coding functions for Asian Cars,
European Cars, US Cars, Australian Car, Supercars, and Trucks.

J2534
Supports J2534 interface standards to
work with vehicle OBDII systems.

Support On Demand (SOD)
SOD offers capability for distributors or tech-support team
to remotely utilizing licensed OEM software to perform
diagnostic, programming, coding, or repair guide.

★ The application software is mainly based on the actual purchase.

Technical Hotline (THL)
Through remote control software, distributors or
tech-support team can remotely operate
i-SCAN 3e and perform necessary functions.

IMS2
IMS2 : patented since 2007
Interface Module Simulation System
for working with OEM software.

Software Update
Connect i-SCAN 3e to Internet then select [UPDATE],
system will detect if new software updates are available.

Setting
For basic system setting and
i-SCAN 3e system information.

AUTOLAND ®
SCIENTECH

i-SCAN 3e Features Overview

Software Download & Update

### Power the scanner by using the DC-12V adapter

DC-12V Switching

Software Update

1. Select SET UP ⚙, then select WiFi connection.
2. After Internet connection is complete, select UPDATE at main page.

3. Entering Software Update, select [Update All] or select [Update] individually.


Printing Function: Using WiFi Printer

1. Setup WiFi printer network connection. Please consult owner's manual for printer.

2. Connect i-SCAN 3e to the same network as the WiFi Printer.

   ★ Please refer to i-SCAN 3e and printer owner's manual for detail.

3. Click printer icon 🖨 in tool bar on the top of screen.

4. Page preview on screen. Select designated printer from the top left selection area to perform printing.

Quick Operational Guide

Step 1 Locate Vehicle Diagnostic Connector

For most vehicles, OBDII connector is located by the driver's seat under the dashboard. Some models may have a lid covering the connector.

Attention:
1. Vehicles manufactured before year of 2000 may be equipped with different connector, or require different connector for different systems. Ex. Toyota before year of 2000 installed the non-OBDII connector under engine hood.
2. Please use correct diagnostic adaptor to connect with vehicle, otherwise connection may fail.

Step 2 Select Diagnostic Adaptor and Connection

1. Connect i-SCAN 3e to vehicle connector via AC-EC5 and corresponding adaptor.
2. After i-SCAN 3e powered on and ready, select [Diagnosis], then select vehicle make.

OBDII AC4-16P

AC-EC5

★Image for illustration only. May differ from each user's i-SCAN 3e depending on the software package purchased.

Fault Code Repair Guide

1. Click on the fault code, i-SCAN 3e will link the user to repair guide database. (Internet connection is required.)

2. Select [A Company] to review fault code related repair guide.

3. Repair guide.